

## Helstu aðgerðir á fjarstýringu



- Kveikja / slökkva
- Power
- Włącznik/Wyłącznik

- Velja inntak
  - Velja HDMI
- Choose source
  - Choose HDMI
- Wybierz źródło
  - Wybierz HDMI

- Hljóðstyrkur
- Volume
- Ustawienia głosu

**ATHUGIÐ:** Valmynd sjónvarps á alltaf að vera stillt á ensku

**Notice:** TV's menu shall always be left on english

**Ważne:** Ustawienia telewizora mają zawsze zostać w języku angielskim

## Ef fjarstýring virkar ekki má kveikja á sjónvarpi á tækinu

### Turning on the TV

You can simply operate the TV functions, using the button.

